

## SINGLE DOOR




30" HIGH	36" HIGH	42" HIGH
W0930	W0936	W0942
W1230	W1236	W1242
W1530	W1536	W1542
W1830	W1836	W1842
W2130	W2136	W2142

## DOUBLE GLASS DOORS WITH DRAWERS



ITEM #	DOORS	DRAWERS
W3630GD6	2	6
W3636GD6	2	6
W3042GD4	2	4
W3642GD6	2	6

## DOUBLE DOOR



12" HIGH	15" HIGH	18" HIGH	24" HIGH	30" HIGH	36" HIGH	42" HIGH
W3012	W3015	W3018	W3024	W2430	W2436	W2442
W3312	W3315	W3318	W3624	W2730	W2736	W2742
W3612	W3615	W3618	W362424	W3030	W3036	W3042
W3912	W3915	W3918		W3330	W3336	W3342
W361224	W361524	W361224		W3630	W3636	W3642
		W361824		W4230	W4236	W4242
				W4830	W4836	W4842

## END ANGLE CORNER




ITEM #
AW30
AW36
AW42

## END PANEL




ITEM #
EPB24D
EPW1230D
EPW1236D
EPW1242D

## CORNER APPLIANCE GARAGE



ITEM #
TAG1224

## DIAGONAL CORNER



ITEM #
WDC2430
WDC2436
WDC2442
WDC273015
WDC273615
WDC274215

## OVEN




ITEM #	DOORS	DRAWERS
OC3384	2	3
OC3390	2	3
OC3396	2	3

## DOUBLE OVEN




ITEM #	DOORS	DRAWERS
P3384OCD	2	1
P3390OCD	2	1
P3396OCD	2	1

**WALL CABINETS BLIND CORNER****ITEM #**

WBC2730L/R  
WBC2736L/R  
WBC2742L/R

**PANTRY WITH 3 DOORS****ITEM #**


WP1884  
WP1890  
WP1896

**PLATE HOLDER****ITEM #**


W3015PL  
W3615PL

**WINE GLASS HOLDER****DOORS**

W30GH  
W36GH

**MICROWAVE OVEN****ITEM #**


MWO301218PM

**WALL END SHELF**

W.	H.	ITEM #
5"	30"	WES530RR
5"	36"	WES536RR
5"	42"	WES542RR

**PANTRY WITH 6 DOORS****ITEM #**


WP2484  
WP2490  
WP2496

**WINE RACK****ITEM #**

W3015PLWR  
W3615PLWR  
W3018PLWR

**OVEN HOOD****ITEM #**

WH30  
WH36

**WALL CABINETS ACCESSORIES: GLASS DOOR**

30"	36"	42"
W1230GD	W1236GD	W1242GD
W1530GD	W1536GD	W1542GD
W1830GD	W1836GD	W1842GD
W2430GD	W2436GD	W2442GD
W3030GD	W3036GD	W3042GD
W3630GD	W3636GD	W3642GD
WDC2430GD	WDC2436GD	WDC2442GD